



**EARTH DRILL
OPERATORS MANUAL**

INDEX



FOREWORD	4
Enquiries	4
The Machinery Directive (European Community only)	4
Declaration Of Conformity	4
REGISTRATION	6
INTRODUCTION	9
SAFETY NOTES	10
Protect Yourself	10
You May Need	10
Know Your Equipment	10
Danger, Warning And Caution	10
Protective And Safety Devices	11
Check The Equipment	11
Hazard Classification (Only applicable to ANSI Safety Labels)	11
Safety Precautions	12
IDENTIFICATION	13
Typical Setup	13
Rope Wind Hitch Parts	14
MOUNTING - HITCH FITTING	15
Single Pin Hitch	15
Double Pin Hitch	16
Cradle Hitch	17
Skid Steer Loader & Telehandler	18
MOUNTING - TRUCK CRANE	19
Linkage Block	19
Rope Wind Hitch	20
Attach Rope Wind Hitch	21
HYDRAULIC CONNECTIONS	22
Rope Wind Hitch	23
Attach Hydraulic Hoses - Earth Drill	23
Attach Hoses - Earth Drill Stop Valve	23
Case drain line fitting	24
Hoses Specifications	25


AIR SYSTEM CONNECTION	26
Rope Wind - Auger Hook Control	26
Auger Hook Air Control - Fitting	27
RUNNING-IN	28
FITTING THE AUGER	29
PREPARATION	30
WORKING PROCEDURE	31
DRILLING WITH FIXED EXTENSIONS	32
REMOVING A FIXED EXTENSION	33
Removing PA Fixed Extensions	34
Multiple Fixed Extensions	34
DRILLING WITH TELESCOPIC EXTENSIONS	35
Fitting A Telescopic Extension	35
ADJUSTING A TELESCOPIC EXTENSION	36
ADJUSTING A PA TELESCOPIC EXTENSION	37
TRANSPORTATION	38
Transportation On Public Highways	38
Transportation Within The Job Site	38
Rope Wind Earth Drill	39
ROPE WIND EARTH DRILL STOWING	40
ROPE WIND AUGER DEPLOYMENT	42
MAINTENANCE & LUBRICATION	44
Daily Check For Larger Units	45
Service Intervals	46
Recommended Oil Change Intervals	47
Oil Change Procedure	48
Recommended Lubricants	49
Component Wear	50
Auger Tooth Replacement	51
Shock Lock Teeth	51
TROUBLESHOOTING	52
WARRANTY STATEMENT	55

FOREWORD

Enquiries

Please state the model type and serial number when making enquiries or orders and all written correspondence. The serial number is recorded on a plate located on the top of the drive unit.

99-5057			AUGERTORQUE®	Distributed by:	
Model:	Serial No:	Weight:			
<input type="text"/>	<input type="text"/>	<input type="text"/>			
Flow Range:	From	To	CE		
Pressure Range:	From	To			
Max. Back Pressure:	<input type="text"/>	Date of Manufacture	<input type="text"/>		



The Machinery Directive (European Community only)

The Machinery Directive 2006/42/EC (formerly 98/37/EEC) provides the harmonisation of the essential health and safety requirements for machinery, through a combination of mandatory health and safety requirements and voluntary harmonised standards. Such directives apply only to products that are intended to be placed on or put into service in the market for the first time. The manufacturer or the authorised representative must draw up a 'Declaration of Conformity'.

Declaration Of Conformity

Where Earth Drill Units are supplied in conjunction with Auger Torque Europe Ltd manufactured mounting frames and Augers to form an Earth Drill Assembly, Auger Torque Europe Ltd have control over the suitability of the parts supplied. To show this and meet with the lawful requirements of the Machinery Directive a Declaration of Conformity is issued and a CE mark is applied to the assembly.

(copy example follows)



AUGER TORQUE

Manufactured By
Auger Torque Europe Limited

EU Declaration of Conformity

The responsible person:

Name	
Position	
Company Name	<i>Auger Torque Europe Ltd.</i>
Address	<i>Hazelton, Cheltenham, GL54 4DX, England</i>
Telephone	<i>++44 (0) 1451 861652</i>
Fax	<i>++44 (0) 1451 861660</i>

Declares that the product described:

Manufacturer	<i>Auger Torque Europe Ltd.</i>
Model	
Serial Number	

Conforms to the Machinery Directive 2006/42/EC.


It also complies with the essential health and safety requirements, national standards and the transposed harmonised standards appropriate for this product.

Signed by:
(The responsible person)

Dated

REGISTRATION

Complete this form and keep it with the manual

		
Auger Torque Europe Ltd Hazleton Cheltenham GL54 4DX England Tel:+44(0)1451 861652 Fax:+44(0)1451 861660 Email: sales@augertorque.com	Auger Torque Australia Pty Ltd 122 Boundary Rd Rocklea Queensland 4106 Australia Tel:+61(0)7 3274 2077 Fax:+61(0)7 3274 5077 Email: sales@augertorque.com.au	Auger Torque USA LLC 100 Commerce Drive Huntington Indiana, 46750 USA Phone: (+1) 260 200 1500 Fax: (+1) 260 200 1501 Email: sales@augertorqueusa.com
MODEL NUMBER:		
SERIAL NUMBER:		
DATE OF MANUFACTURE:		
SUPPLIER / DEALER:		
DATE SOLD TO SUPPLIER / DEALER:		
DATE SOLD TO ORIGINAL END USER:		
OWNER OR OPERATOR:		
PARENT MACHINE MAKE & MODEL:		
Note; Always quote the serial number in any communication with your supplier / dealer		

REGISTRATION

For warranty purposes this form **MUST** be completed and returned to Auger Torque within 14 days of purchase by the end user.



Auger Torque Europe Ltd
Hazleton
Cheltenham
GL54 4DX
England
Tel:+44(0)1451 861652
Fax:+44(0)1451 861660
Email: sales@augertorque.com

Auger Torque Australia Pty Ltd
122 Boundary Rd
Rocklea
Queensland 4106
Australia
Tel:+61(0)7 3274 2077
Fax:+61(0)7 3274 5077
Email: sales@augertorque.com.au

Auger Torque USA LLC
100 Commerce Drive
Huntington
Indiana, 46750
USA
Phone: (+1) 260 200 1500
Fax: (+1) 260 200 1501
Email: sales@augertorqueusa.com

MODEL NUMBER:

SERIAL NUMBER:

DATE OF MANUFACTURE:

SUPPLIER / DEALER:

DATE SOLD TO SUPPLIER / DEALER:

DATE SOLD TO ORIGINAL END USER:

OWNER OR OPERATOR:

PARENT MACHINE MAKE & MODEL:

Note; Always quote the serial number in any communication with your supplier / dealer


For warranty purposes the form on the reverse of this page should be completed and returned to the appropriate address.

Auger Torque Europe Ltd
Hazleton
Cheltenham
GL54 4DX
England
Tel:+44(0)1451 861652
Fax:+44(0)1451 861660
Email: sales@augertorque.com

Auger Torque Australia Pty Ltd
122 Boundary Rd
Rocklea
Queensland 4106
Australia
Tel:+61(0)7 3274 2077
Fax:+61(0)7 3274 5077
Email: sales@augertorque.com.au

Auger Torque USA LLC
100 Commerce Drive
Huntington
Indiana, 46750
USA
Phone: (+1) 260 200 1500
Fax: (+1) 260 200 1501
Email: sales@augertorqueusa.com

Alternatively, if your machine has a pre-installation checks label, like this;-



Just fill in the details on the back and post it to us,
the address is printed on the front.

INTRODUCTION

Auger Torque thank you for purchasing your new product. This operating manual has been prepared to enable you to operate the equipment in a safe manner.

Auger Torque Earth Drill Units have been designed for use with specific Auger Torque mounting frames, Augers, Auger extensions and Auger wear parts. Provided these are used and maintained correctly, they will provide a safe and reliable method of boring holes in the earth.

For information on lubrication and maintenance intervals, see pages 44 to 47

Before operating the Earth Drill, please note:

Your Earth Drill comes complete, filled with the correct amount of oil. There is no need to check the oil level.

Hydraulic hoses must be fitted and tightened to the correct torque (see page 22).

If a case drain hose is fitted to your unit, it must be connected correctly (See page 24).

The unit must be run in following the recommended procedure (see page 28).

NOTE:

This operating manual should be used in conjunction with the parent machine's operating instructions.

Instruction books should be regarded as part of the machine. They should always be kept safe with the machine for easy and quick reference.

New or extra copies can be obtained from your Auger Torque dealer or direct from Auger Torque.

Auger Torque Earth Drill Units have been designed for use with specific parent machines along with the Auger Torque range of mounting frames, Augers, Auger extensions and Auger wear parts. Provided these are used and maintained correctly, they will provide a safe and reliable method of boring holes in the earth.

Auger Torque continually strives to improve and increase its range of products and therefore reserves the right to alter its specifications at any time without notice or obligation. The company accepts no responsibility for discrepancies which may occur between specifications of its machines and descriptions thereof contained in its publications.

SAFETY NOTES

Protect Yourself

Make sure you wear protective clothing and personal safety items.

You May Need

- A Hard Hat
- Safety Goggles
- Hearing Protection
- Foul Weather Clothing
- Reflective Clothing
- Protective Gloves
- Safety Boots

DO NOT wear items of loose clothing, jewellery or other items and tie up any long hair which could entangle in the controls or other parts of the machine.

Know Your Equipment

Get to know all you how to operate all controls on the machine and the attachments

IF THERE IS SOMETHING IN THE MANUAL WHICH YOU DO NOT UNDERSTAND, CONTACT THE MACHINE AGENT OR MANUFACTURER AND ASK THEM TO EXPLAIN IT TO YOU.

Danger, Warning And Caution

This symbol below has 3 important meanings when used with the following captions.



DANGER: An IMMEDIATELY HAZARDOUS situation that WILL result in DEATH or VERY SERIOUS INJURY



WARNING: A POTENTIALLY HAZARDOUS situation that COULD result in DEATH or VERY SERIOUS INJURY



CAUTION: A POTENTIALLY HAZARDOUS situation that MAY result in MINOR INJURY

Protective And Safety Devices

Keep all protective devices in place and securely fastened. Make sure all guards, sheilds and safety signs are properly installed and are in good condition.

Check The Equipment

Before you operate the equipment, take time to check your machine and ensure that all systems are in good operational order.

- Never operate the equipment with worn, damaged or missing parts. Use only genuine replacement parts.
- Always ensure that the parent machine is secure and stable with its engine switched off and hydraulic pipes disconnected before carrying out any maintenance work.
- Check for loose, broken, missing or damaged parts. Have everything put into good repair and make sure all safety devices are in place.
- Perform all maintenance procedures outlined for the equipment.
- Always protect hands. Select appropriate gloves when handling the equipment during fitting, removing or adjusting
- Always protect feet with safety boots.



WARNING: Hydraulic fluid under pressure can penetrate the skin or eyes and cause serious PERSONAL INJURY, BLINDNESS OR DEATH.
Fluid leaks under pressure may not be visible. Use a piece of wood or thick cardboard to find leaks. DO NOT USE YOUR BARE HANDS.
Wear safety goggles for eye protection.
If any fluid is injected into the skin, it MUST be surgically removed.
SEE A DOCTOR IMMEDIATELY

Make sure all hydraulic lines are correctly installed

Before applying pressure to the hydraulic system be sure all connections are tight and that lines, pipes and hoses are not damaged. Before disconnecting hydraulic lines, be sure to relieve all pressure.

Hazard Classification (Only applicable to ANSI Safety Labels)



DANGER: IMMEDIATE HAZARD! - Failure to understand or obey this information is likely to result in personal injury or death.



WARNING: Failure to follow these instructions may result in personal injury or death.



CAUTION: Failure to follow these instructions may result in minor personal injury or damage to the machine or the vehicle.



NOTICE: This is important information for the proper use of this equipment. Failure to comply may lead to premature equipment failure.

CLEAN OR REPLACE THE SAFETY LABELS IF THEY CANNOT BE CLEARLY READ OR UNDERSTOOD

Safety Precautions



NEVER operate or assemble the equipment without **fully** understanding the operating instructions of both the equipment unit and the parent machine.

Auger Torque recommend you receive dealer instruction before operating the unit.

NEVER operate the equipment unless you are in good physical condition and mental health.

NEVER operate the equipment under the influence of any substance (including drugs & alcohol) which might impair vision.

NEVER operate the equipment with worn, damaged or missing parts. Use only genuine replacement parts.

NEVER allow bystanders (including animals) within 6 metres/20 foot of the work area.

NEVER allow minors to operate the equipment.



ALWAYS survey the work area before commencing operations. Check for potential hazards, eg. Electricity or communication cables etc.

ALWAYS ensure that the parent machine is secure and stable with it's engine switched off before carrying out any maintenance work.

ALWAYS ensure the hydraulic oil supply to the attachment is disconnected by uncoupling the hydraulic hose connectors before fitting, removing or adjusting the equipment

ALWAYS wear head protection and eye protection when working on the unit.

ALWAYS protect hands. Select appropriate when handling the equipment during fitting, removing or adjusting the unit.


ALWAYS protect feet. Wear approved safety boots.

ALWAYS follow the parent machine instructions regarding noise protection.


STAY ALERT. Should something break, come loose or fail to operate on your equipment, STOP WORK, lower equipment to the ground, shut off the engine and lock out hydraulic supply, inspect the machine and have repairs or adjustments made before resuming operation.

IDENTIFICATION

Typical Setup



Rope Wind Hitch Parts



MOUNTING - HITCH FITTING

Single Pin Hitch

SAFETY FIRST



ALWAYS work in pairs (2 skilled operatives) whenever Earth Drill unit components are being assembled or disassembled from the parent machine. Always check the weight of the attachment and ensure you have the correct equipment for handling it.



ALWAYS check parent machine:

- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

Check that the mounting frame is of the correct model and type to fit the parent machine. Ensure mounting frame and attachment points are clean before fitting. Use suitably rated lifting equipment if required (see data plate for weight).



NOTE: The single Pin Hitch **CANNOT** be fitted to a quick Hitch.
FITTING Ensure all components are greased on assembly:

Set the Earth Drill unit horizontally, with the output shaft towards the parent machine as in fig A.

There are two types of Pin for fitting the hood to the Mounting Hitch (1):



The **Threaded Mounting Pin** (item 2, fig B) Has a locating plate with a hole that fits over a peg in the hood ear. Align the Pin holes, fit the Pin (2), washer (3) and nylon insert nut (4) and torque to 100Nm/74ft-lb.

To fit the **Through-Bolted Mounting Pin** (item 5, fig C) Align the Pin holes and push the Pin (5) fully home taking care to line up the Through Bolt holes. At both ends of the Pin fit the Through Bolts (6) and Nylon Insert Nuts (7) and tighten to 26Nm/19ft-lb.

Fitting to the parent machine is with through-bolted Pins in all cases:

Align the Pin holes of the mounting Hitch (1) and parent machine. Align bolt location holes fit spacers (8) if required to centralise the Hitch. Push the Pin (9) fully home, taking care to line up the Through Bolt holes. Fit the Through Bolts (10) and Nylon Insert Nuts (11) and tighten to 26Nm/19ft-lb.

Once fitted, check the Earth Drill swings freely in all directions.



Double Pin Hitch

SAFETY FIRST



ALWAYS work in pairs (2 skilled operatives) whenever Earth Drill unit components are being assembled or disassembled from the parent machine. Always check the weight of the attachment and ensure you have the correct equipment for handling it



ALWAYS check parent machine:

- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

Check that the mounting frame is of the correct model and type to fit the parent machine. Ensure mounting frame and attachment points are clean before fitting. Use suitably rated lifting equipment if required (see data plate for weight).



NOTE: If a quick Hitch is fitted to the parent machine, refer to the quick Hitch manufacturer's installation instructions for correct fitting procedure.

FITTING ensure all components are greased on assembly:

Set the Earth Drill unit horizontally, with the output shaft towards the parent machine as in fig A.

There are two types of Pin for fitting the hood to the Mounting Hitch (1):




The **Threaded Mounting Pin** (item 2, fig B) has a locating plate with a hole that fits on a peg in the hood ear. Align the Pin holes, fit the Pin (2), washer (3) and nylon insert nut (4) and torque to 100Nm/74ft-lb.

To fit the **Through-Bolted Mounting Pin** (item 5, fig C), align the Pin holes and push the Pin (5) fully home taking care to line up the Through Bolt holes. At both ends of the Pin fit the Through Bolts (6), Nylon Insert Nuts (7) and tighten to 26Nm/19ft-lb.

There are two types of Pin for fitting the Mounting Hitch (1) to the Parent Machine:

To attach a **Linch Pin** fitting (item 8, fig B), align the Pin holes, push the Pin (8) fully home and fit the linch Pin (9)

To fit the **Through-Bolted Mounting Pin** (10, fig C), align the Pin holes and push the Pin (10) fully home taking care to line up the Through Bolt holes, fit the Through Bolts (11) and Nylon Insert Nuts (12) and tighten to 26Nm/19ft-lb.



Cradle Hitch

SAFETY FIRST



ALWAYS work in pairs (2 skilled operatives) whenever Earth Drill unit components are being assembled or disassembled from the parent machine. Always check the weight of the attachment and ensure you have the correct equipment for handling it



ALWAYS check parent machine:

- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

Check that the mounting frame is of the correct model and type to fit the parent machine. Ensure mounting frame and attachment points are clean before fitting. Use suitably rated lifting equipment if required (see data plate for weight).



NOTE: If a quick Hitch is fitted to the parent machine, refer to the quick Hitch manufacturer's installation instructions for correct fitting procedure.

FITTING Ensure all components are greased on assembly:

Set the Earth Drill Unit horizontally in the cradle Hitch, with the output shaft towards the parent machine as in Fig A.

There are two types of Pin for fitting the Hood to the Mounting Hitch (1):




The **Threaded Mounting Pin** (item 2, Fig B) has a locating plate with a hole that fits on a peg in the hood ear. Align the Pin holes, fit the Pin (2), Washer (3) and Nylon Insert Nut (4) and torque to 100Nm/74ft-lb.

To fit the **Through-Bolted Mounting Pin** (item 5, Fig C), align the Pin holes and push the Pin (5) fully home taking care to line up the Through Bolt holes. At both ends of the Pin fit the Through Bolts (6) and Nylon Insert Nuts (7) and tighten to 26Nm/19ft-lb.

There are two types of Pin for fitting the Mounting Hitch (1) to the Parent Machine:

To attach a **Linch Pin** fitting (item 8, Fig B), align the Pin holes, push the Pin (8) fully home and fit the Linch Pin (9)

To fit the **Through-Bolted Mounting Pin** (item 10, Fig C), align the Pin holes and push the Pin (10) fully home taking care to line up the Through Bolt holes, fit the Through Bolts (11) and Nylon Insert Nuts (12) and tighten to 26Nm/19ft-lb.



Skid Steer Loader & Telehandler

SAFETY FIRST



ALWAYS work in pairs (2 skilled operatives) whenever Earth Drill unit components are being assembled or disassembled from the parent machine. Always check the weight of the attachment and ensure you have the correct equipment for handling it.



ALWAYS check parent machine:


- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

Check that the mounting frame is of the correct model and type to fit the parent machine. Ensure mounting frame and attachment points are clean before fitting. Use suitably rated lifting equipment if required (see data plate for weight).



FITTING: Ensure all components are greased on assembly:

- Slot the top of the parent machine frame under the top edge of the Mounting Frame or Locating Hooks (refer to parent machine operator's manual).
- Swing the parent machine frame to the vertical position.
- Following the parent machine operator's manual, ensure that the Mounting Frame is securely locked in place.
- Working as a pair, lift the Earth Drill in to place with the port opening facing upwards. Align hood ears with the hole in the linkage block. Secure the Earth Drill with the Pin (1), Washer (2) and Nylon Insert Nut (3) and torque to 100Nm/74ft-lb.



MOUNTING - TRUCK CRANE

Linkage Block

SAFETY FIRST



ALWAYS work in pairs (2 skilled operatives) whenever Earth Drill unit components are being assembled or disassembled from the parent machine. Always check the weight of the attachment and ensure you have the correct equipment for handling it



ALWAYS check parent machine:

- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

Check that the mounting frame is of the correct model and type to fit the parent machine.

Ensure mounting frame and attachment points are clean before fitting.

Use suitably rated lifting equipment if required (see data plate for weight).

On Truck Cranes, the Earth Drill is attached via a Linkage Block.

The Linkage Block fits between the hook attachment ears.



FITTING Ensure all components are greased on assembly:

Set the Earth Drill Unit horizontally, with the output shaft towards the parent machine as in Fig A.


The Threaded Mounting Pin has a locating plate with a hole that fits on a peg in the hood ear Fig B. Align the Pin holes in the hood ears and Linkage Block (1), fit the Pin (2), Washer (3) and Nylon Insert Nut (4) and torque to 100Nm/74ft-lb.

Align the holes in the Linkage Block (1) with the attachment ears on the parent machine Fig B.

Insert the mounting Pin (5) and spring clip (6)

Once fitted, check that the Linkage Block swings freely.

Mounting points may differ. (refer to parent machine operator's manual for further information).



Rope Wind Hitch

SAFETY FIRST



ALWAYS work in pairs (2 skilled operatives) whenever Earth Drill unit components are being assembled or disassembled from the parent machine. Always check the weight of the attachment and ensure you have the correct equipment for handling it.



ALWAYS check parent machine:

- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

Check that the mounting Hitch is of the correct model and type to fit the parent machine.


Ensure mounting Hitch and attachment points are clean before fitting.

Use suitably rated lifting equipment if required (see data plate for weight).

Attach Extension Clamp

Dedicated extension clamps are supplied for each model of truck crane.

Fit the 2 halves of the boom clamp with M20 bolts, Nylon Insert Nuts, Washers & Spacers provided and torque to 385Nm/284ft-lb.




Rope Wind Hitch (continued)

Attach Rope Wind Hitch

Fit the hitch with the 2 pins and secure with M10 bolts & nuts. Tighten to 46Nm/34ft-lb.

The Rope wind Hitch is supplied with a Linkage Block fitted. Refer to Linkage Block section to fit Earth Drill (see page 19).



HYDRAULIC CONNECTIONS



WARNING:

Hydraulic fluid under pressure can penetrate the skin or eyes and cause serious personal injury, blindness or death. Fluid leaks under pressure may not be visible. Use a piece of card or wood to find leaks. **DO NOT** use your bare hands. Wear safety goggles to protect your eyes. If any fluid is injected into the skin, it **MUST** be surgically removed. Seek immediate medical attention.

All Auger Torque Earth Drill Units require a 'flow' and 'return' of hydraulic oil from the parent machine's auxiliary hydraulic power supply to operate. All gearboxes are reversible, but require the host machine to be fitted with a two-way flow auxiliary circuit. (Check with parent machine dealer for advice).




When fitting hydraulic hoses, ensure that they are tightened to the correct torque for the hose fittings (Fig A).

Quick Release Couplers are required for connection to the parent machine, but may not be supplied with the unit. These can be sourced locally and should be compatible with the auxiliary hydraulic Quick Release Couplers on the parent machine (Figs B & C). The parent machine auxiliary hydraulic connections are normally located near the end of the loader arms, excavator dipper or truck crane booms.

Ensure that the drilling rotation of the Earth Drill Unit is clockwise.

It is critical that the supply of oil is within the stated flow & pressure limits for the particular Earth Drill;

Refer to the serial plate on the top of the Earth Drill hood (see page 4).



Rope Wind Hitch

Attach Hydraulic Hoses - Earth Drill

Fit the hoses to the motor ports. Tighten to 56Nm/41ft-lb.



Attach Hoses - Earth Drill Stop Valve

A hydraulic valve is fitted at the top of the rope wind hitch.

The purpose of the valve is to stop the rotation of the Auger when it reaches its stowed position.

This function is described in more detail on page 41.

Fit the hoses to the Earth Drill Stop Valve. Tighten to 56Nm/41ft-lb.




Case drain line fitting

Some of the larger Auger Torque Earth Drills are fitted with a case drain line.


This is a flexible hose protruding from the Earth Drill hood and must be connected to a line that returns to the machine's hydraulic fluid reservoir. The parts required to complete this circuit will vary, depending on the machine and the hydraulic equipment fitted. Consequently, case drain hose fittings are not supplied with the Earth Drill and must be sourced separately.

When fitting a case drain line, there must be no restrictions to the flow between the Earth Drill and the reservoir. You **MUST** not use quick release couplings.

You may receive an installation form with your unit, this form must be completed and returned to Auger Torque to validate the warranty.



Hoses Specifications



Minimum hydraulic hose requirements		
Model	Minimum internal hose diameter (in/mm)	Minimum working pressure Bar/PSI
1200 / 900-9	1/2" / 12.7mm	185Bar / 2680PSI
X1500 / X1100-13	1/2" / 12.7mm	205Bar / 2973PSI
X2000 / X1600-15	1/2" / 12.7mm	240Bar / 3480PSI
X2500 / X2100-17	1/2" / 12.7mm	240Bar / 3480PSI
ML1500 / ML1100-13	1/2" / 12.7mm	205Bar / 2973PSI
ML2000 / ML1600-15	1/2" / 12.7mm	240Bar / 3480PSI
ML2500 / ML2100-17	1/2" / 12.7mm	240Bar / 3480PSI
3000MAX / 2200-20	1/2" / 12.7mm	240Bar / 3480PSI
3500MAX / 2700-25	1/2" / 12.7mm	240Bar / 3480PSI
4500MAX / 3300-30	1/2" / 12.7mm	240Bar / 3480PSI
5000 / 3700-30	1/2" / 12.7mm	240Bar / 3480PSI
5500MAX / 4000-30	1/2" / 12.7mm	240Bar / 3480PSI
7000 / 5000-30	1/2" / 12.7mm	260Bar / 3771PSI
7000MAX / 5200-35	3/4" / 19.0mm	260Bar / 3771PSI
8000MAX / 6000-40	3/4" / 19.0mm	240Bar / 3480PSI
10 000 / 8000-40	3/4" / 19.0mm	240Bar / 3480PSI
12 000 / 9500-40	3/4" / 19.0mm	240Bar / 3480PSI
12 000MAX / 9000-45	1" / 25.4mm	240Bar / 3480PSI
15 000 / 11000-40	3/4" / 19.0mm	240Bar / 3480PSI
15 000MAX / 11000-45	1" / 25.4mm	240Bar / 3480PSI
17 000MAX / 12500-45	1" / 25.4mm	260Bar / 3770PSI
20 000MAX / 15000-45	1" / 25.4mm	240Bar / 3480PSI
25 000MAX / 18500-45	1" / 25.4mm	240Bar / 3480PSI
30 000 / 20000-45	1" / 25.4mm	240Bar / 3480PSI
30 000MAX / 24000-80	1 1/4" / 31.8mm	450Bar / 6526PSI
35 000MAX / 26000-60	1" / 25.4mm	310Bar / 4496PSI
40 000 / 32000-45	1" / 25.4mm	240Bar / 3480PSI
42 000MAX / 31000-60	1" / 25.4mm	310Bar / 4496PSI
50 000MAX / 35000-80	1 1/4" / 31.8mm	320Bar / 4640PSI
3000TC / 2300-10	1/2" / 12.7mm	260Bar / 3771PSI
5500TC / 4000-14	1/2" / 12.7mm	260Bar / 3771PSI
7000TC / 5000-14	1/2" / 12.7mm	260Bar / 3771PSI

Replacement hydraulic hoses **MUST** be rated equal or greater than the minimum working pressure.

AIR SYSTEM CONNECTION

Rope Wind - Auger Hook Control

The Auger retention hook is operated by a momentary valve, which operates as follows;-


Normal state = OFF (Fig.1):

With the button in it's Normal state, the system is vented and the Auger hook is retained in its closed position under spring tension.

Pressed = ON (Fig. 2):

While the operating button is depressed, the valve pressurises the system and opens the retaining hook.

Releasing the button returns the vale to the Normal (vented) state (Fig.1), allowing the hook to return to its closed position under spring tension.



When using compressed air, you should be aware of the following safety guidelines:



NEVER point an air hose at anyone, including yourself.

ALWAYS wear adequate eye protection. Use safety glasses with side shields or goggles.



BEFORE using compressed air, check the air hose for damage or signs of failure. Make sure connections and couplings are tight.


BEFORE disconnecting an air line, the air should be cut off, and the remaining air bled from the line.



ALWAYS keep air hoses off the floor where they become tripping hazards and are subject to damage.

Auger Hook Air Control - Fitting

The control valve must be fitted close to the parent machine controls. It requires a compressed air supply of no more than 10bar (145psi).



RUNNING-IN


To maximise the life of the unit, it must be run in for a period .

To carry out the running in procedure, suspend the Earth Drill in it's vertical, working position.

For the duration of the running in procedure, ensure that no bystanders (including animals) can get within 6 metres/20 foot of the work area.

Operate the motor at 30% of rated pressure for 20 minutes in each direction before application of full operating load.

To further ensure best motor life and maintain warranty, refer to page 45 for lubrication instructions.



FITTING THE AUGER

SAFETY FIRST



ALWAYS work in pairs (2 skilled operatives) whenever Earth Drill Unit components are being assembled or disassembled from the parent machine.



ALWAYS check parent machine:

- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

CHECK that the Auger is the correct model and type to fit the Earth Drill Unit.

ENSURE that the Auger connections are clean before fitting.

USE suitably rated lifting equipment if required (see data plate for weight).


Position the Auger in the vertical work position and support it so that it cannot fall over.

Position the Earth Drill over the Auger and align the pin holes.

Lower the Earth Drill Unit onto the Auger

Locate the Auger Drive Pin

Secure the Auger Drive Pin with Linch Pin



PREPARATION



CONSIDER the topography (e.g. risk of subsidence, slope angle, position to embankments and any previous excavation).




NOTE the type of soil and its condition to enable selection of suitable teeth and pilot

ALWAYS carry out a site survey and risk assessment **BEFORE** starting work



AVOID underground hazards, such as water / gas / electricity / communication lines etc.

If in doubt detection equipment and professional advice should always be considered before carrying out any work.



WORKING PROCEDURE

Before commencing work, ensure that ;



The correct hoses are fitted and tightened correctly (See page 22).
The unit has been properly run in (See page 28).



There are no bystanders are within 6 metres / 20 foot of the work area.

SET Auger in a vertical drilling position (Fig A).
ENSURE the direction of rotation is **CLOCKWISE**.
ONLY start drilling after a site survey on a pre-marked safe location (see page 30).

GRADUALLY lower the parent machine arm(s) to apply down force to the Auger.

The harder the ground the more down force required.

Maintain drilling speed. **DO NOT CONTINUALLY STALL** the Earth Drill unit with excessive down force, as this will overheat the hydraulic oil and could damage the machine.

KEEP THE AUGER VERTICAL;

For skid steer machines (Fig B);

Adjust the angle of the arms, mounting frame and the position of the parent machine as necessary.

For excavators (Fig C);

Adjust the angle of the dipper and boom.





MAXIMISE efficiency and avoid damaging the Auger assembly by keeping the Auger vertical.

REGULARLY raise the Auger out of the ground to clear material from the Auger. This will help maintain drilling effectiveness and ensure your machine does not become unstable.

NEVER Drill beyond the length of the Auger.

NEVER leave the Auger assembly suspended.


ALWAYS park with the Auger on the ground.



DRILLING



PARKING



DRILLING WITH FIXED EXTENSIONS

When the required hole depth is greater than the length of the Auger, an Extension should be used. **DO NOT** allow the Earth Drill to enter the hole as seals can be damaged by spoil being extracted.

SAFETY FIRST



Whenever Earth Drill Unit components are being assembled or disassembled from the parent machine **ALWAYS** work in pairs (2 skilled operatives). While fitting components,



ALWAYS check parent machine:

- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

CHECK that the Extension is the correct model and type to fit the Earth Drill Unit and Auger.

ENSURE that all Earth Drill, Auger and Extension connections are clean before fitting.


USE suitably rated lifting equipment if required.

When using extensions in drilling operations, a length of timber is required for supporting the Auger while removing the Extension. The timber must be of minimum dimensions 150mm (6") deep x 50mm (2") wide and long enough to span the hole being drilled, plus an additional 300mm (12") length at each end.

Fitting A Fixed Extension

When the hole has been drilled to the point where the top of the auger comes within 200mm (8") above ground level;


- Stop drilling.
- Remove the auger from the hole and clear the spoil from the auger.
- Lower the auger back into the hole so that its' weight is supported and remove the Linch Pin and Auger Drive Pin.
- Lift the Earth Drill clear of the Auger and slew it to one side, clear of the hole and set it to a height that will allow the extension to be fitted easily.
- Position the Extension in the vertical work position and support it so that it cannot fall over.
- Position the Earth Drill over the Extension and align the pin holes.
- Lower the Earth Drill Unit onto the Extension.
- Insert the Extension Drive Pin.
- Secure the Extension Drive Pin with Linch Pin.
- Position the Earth Drill and Extension over the Auger and align the pin holes.
- Lower the Earth Drill and Extension onto the Auger.
- Insert the Auger Drive Pin.
- Secure the Auger Drive Pin with Linch Pin.
- Continue drilling.



REMOVING A FIXED EXTENSION

If the parent machine has a high reach, it may be possible to lift the auger clear of the hole to clear the spoil without removing the Extension. For smaller machines, and in cases where multiple Extensions are being used, it may be necessary to remove the Extension first.

- Lift the Earth Drill until the Auger Flight is clear of the ground and insert the timber support through the Auger Flight.
- Lower the Earth Drill until the weight of the Auger and Extension are supported by the timber. Make sure that the load is spread equally on either side of the hole.
- Remove the Linch Pin and Auger Drive Pin.
- Lift the Earth Drill until the Extension is clear of the Auger and slew it to one side, clear of the hole and set it to a height that will allow safe removal of the extension.
- Support the weight of the Extension.
- Remove the Linch Pin and Extension Drive Pin.
- Remove the Extension and lay it on the ground.
- Position the Earth Drill over the Auger and align the pin holes.
- Lower the Earth Drill Unit onto the Auger.
- Insert the Auger Drive Pin.
- Secure the Auger Drive Pin with the Linch Pin.
- Lift the Earth Drill to remove the load from the timber support.
- Remove the timber support.




Removing PA Fixed Extensions

If the parent machine has a high reach, it may be possible to lift the auger clear of the hole to clear the spoil without removing the Extension. For smaller machines, and in cases where multiple Extensions are being used, it may be necessary to remove the Extension first.

- Lift the Earth Drill until the Auger Handle is clear of the ground and insert the timber support through the handle.
- Lower the Earth Drill until the weight of the Auger and Extension are supported by the timber. Make sure that the load is spread equally on either side of the hole.
- Remove the Linch Pin and Auger Drive Pin.
- Lift the Earth Drill until the Extension is clear of the Auger and slew it to one side, clear of the hole and set it to a height that will allow safe removal of the extension.
- Support the weight of the Extension.
- Remove the Linch Pin and Extension Drive Pin.
- Remove the Extension and lay it on the ground.
- Position the Earth Drill over the Auger and align the pin holes.
- Lower the Earth Drill Unit onto the Auger.
- Insert the Auger Drive Pin.
- Secure the Auger Drive Pin with the Linch Pin.
- Lift the Earth Drill to remove the load from the timber support.
- Remove the timber support.

Multiple Fixed Extensions

Following the procedures above, multiple fixed Extensions may be added to further increase the hole depth. As with the Auger, each Extension is fitted with a handle through which the timber support can be inserted to support the Extension while adding or removing additional Extensions.



DRILLING WITH TELESCOPIC EXTENSIONS

Telescopic Extensions enable the drilling holes deeper than the Auger length, without the need to remove the Extension to extract the Auger.

DO NOT allow the Earth Drill to enter the hole as seals can be damaged by spoil being extracted.

SAFETY FIRST



Whenever Earth Drill Unit components are being assembled or disassembled from the parent machine **ALWAYS** work in pairs (2 skilled operatives).



While fitting components, **ALWAYS** check parent machine:


- Is in correct working order
- Is parked correctly on flat ground
- Has its hand brake **ON**, its hydraulic circuit locked out and its engine switched **OFF**.

CHECK that the Extension is the correct model and type to fit the Earth Drill Unit and Auger.

ENSURE that all Earth Drill, Auger and Extension connections are clean before fitting.

USE suitably rated lifting equipment if required.

When using Telescopic Extensions in drilling operations, a length of timber is required for supporting the Auger while adjusting the Extension. The timber must be of minimum dimensions 150mm (6") deep x 50mm (2") wide and long enough to span the hole being drilled, plus an additional 300mm (12") length at each end.




Fitting A Telescopic Extension

NOTE: The Telescopic Extension Hub is bolted to the Extension Shaft, **DO NOT** remove this bolt. The extension is fixed to the Auger with a pin and linch pin.

The Telescopic Extension can be fitted before drilling commences:

- Insert the Extension into the Auger, ensuring that the pin holes line up.
- Fix the extension to the Auger at the top pin hole (the shortest setting).
- Position the Auger and Extension in the vertical work position and support it so that it cannot fall over.
- Position the Earth Drill over the Auger and Extension align the pin holes.
- Lower the Earth Drill Unit onto the Extension.
- Insert the Extension Drive Pin.
- Secure the Extension Drive Pin with Linch Pin.
- Commence drilling.




ADJUSTING A TELESCOPIC EXTENSION

To adjust the Extension length:

- Lift the Earth Drill until the Auger Flight is clear of the ground and insert the timber support through the Auger Flight.
- Lower the Earth Drill until the weight of the Auger and Extension are supported by the timber. Make sure that the load is distributed equally on either side of the hole.
- Remove the Linch Pin and Auger Drive Pin.
- Lift the Earth Drill until the desired Extension length is achieved and the holes in the Auger and Extension line up.

NOTE: The shaft of the Telescopic Extension has a red painted portion at the bottom end. When lifting the shaft out to increase the Extension length, the appearance of the red area above the Auger hub indicates that you are approaching the longest setting and the end of the shaft. Careful height adjustment in this area prevents the shaft coming out of the Auger and having to be lined up and re-inserted.

- Insert the Auger Drive Pin.
- Secure the Auger Drive Pin with the Linch Pin.
- Lift the Earth Drill to remove the load from the timber support.
- Remove the timber support.




ADJUSTING A PA TELESCOPIC EXTENSION

To adjust the Extension length:

- Lift the Earth Drill until the Auger Handle is clear of the ground and insert the timber support through the handle.
- Lower the Earth Drill until the weight of the Auger and Extension are supported by the timber. Make sure that the load is distributed equally on either side of the hole.
- Remove the Linch Pin and Auger Drive Pin.
- Lift the Earth Drill until the desired Extension length is achieved and the holes in the Auger and Extension line up.

NOTE: The shaft of the Telescopic Extension has a red painted portion at the bottom end. When lifting the shaft out to increase the Extension length, the appearance of the red area above the Auger hub indicates that you are approaching the longest setting and the end of the shaft. Careful height adjustment in this area prevents the shaft coming out of the Auger and having to be lined up and re-inserted.

- Insert the Auger Drive Pin.
- Secure the Auger Drive Pin with the Linch Pin.
- Lift the Earth Drill to remove the load from the timber support.
- Remove the timber support.



TRANSPORTATION

When attached to the parent machine the standard Auger Unit is free to swing and can be extremely dangerous during transport.

Transportation On Public Highways

ALWAYS remove the Auger and Earth Drill before driving or transporting the parent machine on public highways.


ALWAYS store the Auger and Earth Drill securely and safely when removed from the parent machine taking special care of the hydraulic hoses and connections.

Transportation Within The Job Site

ALWAYS operate the parent machine slowly when on site taking great care to avoid the Auger swinging.

RECOMMENDED: where fitted use the hitch cradle to support the Earth Drill Unit when manoeuvring on site.

Cradle Hitch Support



Rope Wind Earth Drill

Whether the vehicle is being moved on public road or on site, the Earth Drill and Auger **MUST** be secured in the **STOWED** position. The unit **MUST** be supported by the Auger Retention Hook **NOT** the Rope.

SAFETY INSTRUCTIONS



Before using the rope to stow the Earth Drill and Auger, **ALWAYS** carry out these safety checks:

ALWAYS:

- Follow safe practices as supplied with your rope
- Store and handle the rope correctly to avoid damage
- Inspect the rope before use, and before storing
- Replace the rope after one years use
- Lift the load steadily to avoid shock loading
- Check all equipment is free from damage
- Regularly inspect the rope for wear and damage

NEVER;

- Exceed safe working load
- Use at temperature exceeding 100 degrees or below -40 degrees
- Expose the rope to chemicals without consulting supplier
- Use if there are any cuts or loose stitching
- Leave the Earth Drill/Auger suspended by the rope




ROPE WIND EARTH DRILL STOWING

Before using the Stowage Rope, **ALWAYS** refer to the **STOWAGE ROPE SAFETY INSTRUCTIONS**

STEP 1 - Attach rope.

NOTE: Only use the supplied rope for stowing the Auger, check that it is in good condition and replace it after one years use.


- A Pass one end of the rope through the attachment loop on the hitch frame.
- B Pass the other end of the rope through the loop in the first end and pull tight to secure. Thread the loop on the second end on to the hook on the Auger.



STEP 2 - Retract Earth Drill & Auger


Rotate the Earth Drill in the cutting direction.

The rope will wind around the Auger shaft. When the rope becomes tight, the Earth Drill and Auger will be pulled towards the Stowage Slot.



STEP 3 - Stowage position

As the Auger reaches the Stowage Slot, the Auger will automatically operate the Auger retention hook and lock into place.




STEP 4 - Secure the Auger

When the Auger reaches it's stowed position, the stop valve is operated.


The valve plunger is operated by contact with the Earth Drill output housing when the Auger has reached it's maximum height. The valve diverts hydraulic fluid from the earth Drill motor, stopping Auger rotation.

Check that the Auger Retention Hook has engaged.




STEP 5 - Release load from rope

With the Auger Retention Hook engaged, reverse the Earth Drill until the rope is slack and the Auger is supported on the Hook.



ROPE WIND AUGER DEPLOYMENT


STEP 1 - Rotate the Earth Drill in the cutting direction to apply tension to the rope and lift the Auger clear of the Auger Retention Hook.




STEP 2 - Press the Auger Retention Hook operating button to release the Hook.

Reverse the Earth Drill to lower the Auger.


Once the Auger is out of the Auger Storage Slot, release the button and allow the Auger Retention Hook to close.



STEP 3 - Keep the Earth Drill rotating in the reverse direction until the Auger hangs vertically.
Stop the Earth Drill.



STEP 4 - Remove the rope and stow it safely, away from direct sunlight, moisture and contaminants.



MAINTENANCE & LUBRICATION

SAFETY



Safety at all times



Ensure environmentally safe disposal of waste oil:

Do not pour down drain!



Avoid Fire or Explosion:

Do not smoke near, or expose lubricants to, any possible sources of ignition (e.g. fire, electrical sparks or heat sources.)



All lubricants are toxic and potentially carcinogenic (cancer causing).



Avoid contact with skin and eyes:

Wear suitable protective clothing and gloves.



Always use a suitable barrier cream in case of skin contact.



Always wear eye protection:

In the event of skin contact wash with soap and water.

In the event of eye contact wash with water and seek medical advice.



Do not ingest:

If swallowed seek medical advice immediately.

Daily Check For Larger Units

SPECIAL NOTE

This page applies only to models:


17,000MAX - 20,000MAX - 25,000MAX - 30,000 - 30,000MAX - 35,000MAX

40,000 - 42,000MAX - 50,000MAX

12500-45 - 15000-45 - 18500-45 - 20000-45 - 24000-80 - 26000-60

31000-60 - 32000-45 - 35000-80

The following daily check **MUST** be carried out prior to any operation of the Earth Drill unit.



1. With the Earth Drill unit secured in a vertical position. Remove the sight glass guard plate to gain access to the sight glass and check the oil level
2. If the sight glass is fully filled with oil, the unit is filled to an acceptable level.
3. If the sight glass is only partially filled with oil, top up using the oil fill/level point, until the acceptable level is achieved. Ensure that the correct grade of oil is used. This information can be found on the label (shown above) fitted to the Earth Drill unit.

Service Intervals

Your Auger Torque Europe Ltd Earth Drill Unit features a sealed gear housing filled with gear oil to lubricate the planetary gearset components and bearings within the housing.

Auger Torque Europe Ltd Earth Drill Units are low maintenance, however regular checks for oil leaks and following the service schedules are recommended to ensure a trouble free product.

Weekly:

Grease hitch and Earth Drill pivot pins.


Oil Lubrication

Your Earth Drill has been prefilled with Gear Oil. This oil requires regular changing, changing the oil at regular intervals will prolong the life of you unit.

Please refer to the chart on page 47 for recommended oil change intervals.

Important: To maintain product warranty your Auger Torque Dealer **MUST** record proof of this first oil change.

Please note: the first oil change is free of charge provided that an Authorised Auger Torque service representative carries it out.



PROOF OF FIRST SERVICE

Dealer Stamp

Dealer Name.....

Date Serviced.....

Recommended Oil Change Intervals

Oil change frequency		
Model	First oil change after initial use	Subsequent oil change frequency
1200 / 900-9	3 Months or 200 hours*	12 Months or 800 hours*
X1500 / X1100-13	3 Months or 200 hours*	12 Months or 800 hours*
X2000 / X1600-15	3 Months or 200 hours*	12 Months or 800 hours*
X2500 / X2100-17	3 Months or 200 hours*	12 Months or 800 hours*
ML1500 / ML1100-13	3 Months or 200 hours*	12 Months or 800 hours*
ML2000 / ML1600-15	3 Months or 200 hours*	12 Months or 800 hours*
ML2500 / ML2100-17	3 Months or 200 hours*	12 Months or 800 hours*
3000TC / 2300-10	3 Months or 200 hours*	12 Months or 800 hours*
3000MAX / 2200-20	3 Months or 200 hours*	12 Months or 800 hours*
3500MAX / 2700-25	3 Months or 200 hours*	12 Months or 800 hours*
4500MAX / 3300-30	3 Months or 200 hours*	12 Months or 800 hours*
5000 / 3700-30	3 Months or 200 hours*	12 Months or 800 hours*
5500TC / 4000-14	3 Months or 200 hours*	12 Months or 800 hours*
5500MAX / 4000-30	3 Months or 200 hours*	12 Months or 800 hours*
7000 / 5000-30	3 Months or 200 hours*	12 Months or 800 hours*
7000TC / 5000-14	3 Months or 200 hours*	12 Months or 800 hours*
7000MAX / 5200-35	2 Months or 120 hours*	12 Months or 800 hours*
8000MAX / 6000-40	2 Months or 120 hours*	12 Months or 800 hours*
10000 / 8000-40	2 Months or 120 hours*	12 Months or 800 hours*
12000 / 9500-40	2 Months or 120 hours*	12 Months or 800 hours*
12000MAX / 9000-45	2 Months or 120 hours*	12 Months or 800 hours*
15000 / 11000-40	2 Months or 120 hours*	12 Months or 800 hours*
15000MAX / 11000-45	2 Months or 120 hours*	12 Months or 800 hours*
17000MAX / 12500-45	1 Month or 50 hours*	4 Months or 200 hours*
20000MAX / 15000-45	1 Month or 50 hours*	4 Months or 200 hours*
25000MAX / 18500-45	1 Month or 50 hours*	4 Months or 200 hours*
30000 / 20000-45	1 Month or 50 hours*	4 Months or 200 hours*
30000MAX / 24000-80	1 Month or 50 hours*	4 Months or 200 hours*
35000MAX / 26000-60	1 Month or 50 hours*	4 Months or 200 hours*
40000 / 32000-45	1 Month or 50 hours*	4 Months or 200 hours*
42000MAX / 31000-60	1 Month or 50 hours*	4 Months or 200 hours*
50000MAX / 35000-80	1 Month or 50 hours*	4 Months or 200 hours*

* Whichever time period occurs first.

Oil Change Procedure




Before starting any maintenance work on this unit, read the instructions carefully and ensure you have the correct tools, materials and safety equipment to hand.

NOTE: The procedure described below should be carried out by a competent and proficient engineer.

1. Pre-heat the oil by running the unit for 15 minutes (Fig A). Ensure that the unit is safely supported in a horizontal position, with the fill & drain plugs (Fig B, 1 & 2) at top and bottom of the housing
2. Remove drain & fill plugs using suitable tooling and allow oil to drain for a minimum of 10 minutes. For best results leave to drain overnight.
3. Refit drain plug (Fig C, 2) and fill with oil.

Refer to page 49 for correct oil grades and quantities.

4. Refit fill plug (Fig C, 1).
5. Check for signs of leakage, refill as necessary.



Recommended Lubricants

Model	Oil Quantity ml	Grade	Type
1200	150	EP 320	Mineral
X1500	400	EP 320	Mineral
X2000	400	EP 320	Mineral
X2500	400	EP 320	Mineral
ML1500	400	EP 320	Mineral
ML2000	400	EP 320	Mineral
ML2500	400	EP 320	Mineral
3000TC	850	EP 320	Mineral
3000MAX	850	EP 320	Mineral
3500MAX	850	EP 320	Mineral
4500MAX	850	EP 320	Mineral
5000	1250	EP 320	Mineral
5500TC	1250	EP 320	Mineral
5500MAX	1250	EP 320	Mineral
7000	1250	EP 320	Mineral
7000TC	1250	EP 320	Mineral
7000MAX	1250	EP 320	Mineral
8000MAX	1250	EP 320	Mineral
10 000	2150	EP 320	Mineral
12 000	2150	EP 320	Mineral
12 000MAX	2150	EP 320	Mineral
15 000	2150	EP 320	Mineral
15 000MAX	2150	EP 320	Mineral
17 000MAX	6750	EP 320	Mineral
20 000MAX	6750	EP 320	Mineral
25 000MAX	6750	EP 320	Mineral
30 000	8000	SY 320	Polyglycol
30 000MAX	8000	SY 320	Polyglycol
35 000MAX	8000	SY 320	Polyglycol
40 000	8000	SY 320	Polyglycol
42 000MAX	8000	SY 320	Polyglycol
50 000MAX	8800	SY 320	Polyglycol




Model	Oil Quantity US pints	Grade	Type
900-9	0.32	AGMA 6EP	Mineral
X1100-13	0.85	AGMA 6EP	Mineral
X1600-15	0.85	AGMA 6EP	Mineral
X2100-17	0.85	AGMA 6EP	Mineral
ML1100-13	0.85	AGMA 6EP	Mineral
ML1600-15	0.85	AGMA 6EP	Mineral
ML2100-17	0.85	AGMA 6EP	Mineral
2300-10	1.79	AGMA 6EP	Mineral
2200-20	1.79	AGMA 6EP	Mineral
2700-25	1.79	AGMA 6EP	Mineral
3300-30	1.79	AGMA 6EP	Mineral
3700-30	2.64	AGMA 6EP	Mineral
4000-14	2.64	AGMA 6EP	Mineral
4000-30	2.64	AGMA 6EP	Mineral
5000-30	2.64	AGMA 6EP	Mineral
5000-14	2.64	AGMA 6EP	Mineral
5200-35	2.64	AGMA 6EP	Mineral
6000-40	2.64	AGMA 6EP	Mineral
8000-40	4.54	AGMA 6EP	Mineral
9500-40	4.54	AGMA 6EP	Mineral
9000-45	4.54	AGMA 6EP	Mineral
11000-40	4.54	AGMA 6EP	Mineral
11000-45	4.54	AGMA 6EP	Mineral
12500-45	14.26	AGMA 6EP	Mineral
15000-45	14.26	AGMA 6EP	Mineral
18500-45	14.26	AGMA 6EP	Mineral
20000-45	16.90	AGMA 9005 E02	Polyglycol
24000-80	16.90	AGMA 9005 E02	Polyglycol
26000-60	16.90	AGMA 9005 E02	Polyglycol
32000-45	16.90	AGMA 9005 E02	Polyglycol
31000-60	16.90	AGMA 9005 E02	Polyglycol
35000-80	18.59	AGMA 9005 E02	Polyglycol

All units are supplied with 320 / AGMA 6EP viscosity oil unless otherwise requested.
 When using or storing the units below -15°C a 150 / AGMA 4EP viscosity oil must be used.
 When using or storing units above 35°C a 460 / AGMA 7EP viscosity oil must be used.

Component Wear

The cutting teeth and pilot should be checked regularly for wear. The diagrams below show acceptable levels of wear.

NOTE; Excessively worn teeth & pilots may cause damage to the Auger



NOTE; Pilots can be replaced by unbolting the old pilot and bolting the new one in it's place. For tooth replacement, refer to page 51.

Auger Tooth Replacement

NOTE; Before removing Auger teeth, ensure that the Auger is horizontal and securely supported with the teeth easily accessible. Always wear appropriate protective clothing.

Shock Lock Teeth

Use a 5mm pin punch to drive the retaining pin out through the top of the tooth holder. The tooth and Shock Lock rubber can then be withdrawn.



To install a replacement Shock Lock tooth, fit the rubber into the slot in the tooth.

Press the tooth and rubber into the tooth holder, ensuring that the cut-out for the pin is on the correct side. You may need to use a soft-faced hammer to drive it in fully.

Insert a new retaining pin into the top of the tooth holder, plain end first.

Drive the pin in, ensuring that it locates in the cut-out in the tooth.

Use a pin punch to make sure that the knurled end of the pin is fully engaged in the hole.



TROUBLESHOOTING

IF IN DOUBT ASK! - Seek Auger Torque / parent machine dealer for advice & repair.

BE SAFE - only use genuine Auger Torque / parent machine spare parts.

MOUNTING FRAME - ASSEMBLY		
FAULT	POSSIBLE CAUSE	ACTION
Mounting frame does not fit parent machine	Incorrect or non-genuine mounting frame being used Damaged / worn parts	Refer to both this manual and parent machine's operating assembly instructions Repair or replace with genuine mounting frame
MOUNTING FRAME - OPERATION		
FAULT	POSSIBLE CAUSE	ACTION
Excessive movement in locating pins	Incorrect or worn locating pins Parent machine pin location / linkage frame pin location worn Damaged parts	Replace with correct new parts Seek advice from parent machine dealer Seek advice from Auger Torque / parent machine dealer. Only use genuine spare parts
AUGER DRIVE UNIT - ASSEMBLY		
FAULT	POSSIBLE CAUSE	ACTION
Earth Drill Unit will not fit mounting frame	Incorrect / incompatible or non genuine mounting frame / Earth Drill Unit Damaged parts	Obtain & fit correct and compatible genuine parts Seek advice from Auger Torque dealer. Only use genuine spare parts
Excessive movement in locating pins	Incorrect or worn pins	Replace with correct new genuine parts
EARTH DRILL UNIT - OPERATION		
FAULT	POSSIBLE CAUSE	ACTION
Earth Drill output shaft does not rotate	No oil flow	Check that quick release coupler(s) are correctly engaged to parent machine Check that parent machine hydraulic system is operating correctly and has sufficient oil of the correct grade (refer to parent machine operating instructions)

EARTH DRILL UNIT - OPERATION

FAULT	POSSIBLE CAUSE	ACTION
Earth Drill output shaft does not rotate	<p>Parent machine pressure relief valve faulty or set too low</p> <p>Earth Drill unit seized</p> <p>Auger jammed in ground</p>	<p>Test, reset or replace to parent machine's specification</p> <p>Seek advice from Auger Torque dealer</p> <p>Remove auger from ground before starting machine</p>
Slow digging speed / slow rotation of Earth Drill output shaft	<p>Insufficient oil flow from parent machine</p> <p>Incompatible Earth Drill to parent machine combination</p> <p>Incorrect auger, boring teeth or pilot fitted or worn boring teeth/pilot</p> <p>Worn Earth Drill hydraulic motor possibly due to incorrect or dirty oil supply</p>	<p>Check the parent machine hydraulic system is operating correctly and has sufficient oil of the correct grade</p> <p>Check specification. Seek advice from Auger Torque dealer</p> <p>Ensure auger size is compatible with Earth Drill Unit (not too large) and that boring teeth/pilot are suitable for the ground conditions and not worn</p> <p>Seek advice from Auger Torque dealer. Only use genuine spare parts. Change parent machine hydraulic oil and filter before fitting replacement drive unit</p>
Auger stalls during work	<p>Parent machine pressure relief valve faulty or set too low</p> <p>Restricted oil flow</p> <p>Blocked hydraulic filter</p> <p>Excessive parent machine down force on auger</p> <p>Incompatible Earth Drill / auger size / parent machine combination</p>	<p>Reset/replace pressure release valve to parent machine's specification</p> <p>Check for damaged or incorrect hydraulic hoses and connections</p> <p>Change parent machine filter and oil</p> <p>Reduce down force</p> <p>Check specification. Seek advice from Auger Torque dealer</p>

ROPE WIND HITCH

FAULT	POSSIBLE CAUSE	ACTION
Rotation doesn't stop when Earth Drill and auger reach top of stowage slot	<p>Poor adjustment of valve</p> <p>Faulty valve</p>	<p>Adjust position of valve</p> <p>Check valve and if necessary, replace</p> <p>Check hose connections to valve</p>
Retention hook doesn't open	<p>Auger is supported by hook</p> <p>Faulty air supply</p> <p>Faulty air valve</p> <p>Faulty hook operating cylinder</p>	<p>Lift auger clear of hook by rotating the Earth Drill</p> <p>Check air hose to valve, repair or replace as necessary</p> <p>Check air valve operation, replace as necessary</p> <p>Check cylinder operation, replace as necessary</p>
Retention hook doesn't close	<p>Earth Drill and auger have not reached top of stowage slot</p> <p>Faulty hook operating cylinder</p> <p>Broken return spring</p> <p>Pivot bolt too tight</p>	<p>Lift auger to top of stowage slot by rotating the Earth Drill</p> <p>Check cylinder operation, replace as necessary</p> <p>Replace</p> <p>Check and re-set as necessary</p>

WARRANTY STATEMENT

Auger Torque provide a LIFETIME parts replacement warranty on the dislodgement of the Earth Drill shaft and any failure of the Shock Lock system to prevent loss of teeth under normal operating conditions.

All Auger Torque products are warranted to be free from defects in materials or workmanship for the periods summarised below:

- Planetary Gearbox Components - 72 Months
- Hydraulic Motors - 36 Months
- All Other Parts / Products - 12 Months

The warranty periods will commence from Date of Sale by an authorised Auger Torque Dealer. Evidence of the date of sale may be required and for Planetary and Hydraulic Motor warranties to be valid the product must be registered with Auger Torque within 4 weeks of the date of sale. Extended Warranty (> 12 months) Products can be registered by returning the Registration Card or completing the form on page 7. This warranty is not transferable beyond the initial purchaser of the product.

A warranty claim should be reported to the Auger Torque Dealer who supplied the unit. The Dealer, with the technical backup of Auger Torque, will make an initial assessment.

The customer is responsible for returning the product for warranty inspection to the original supplying dealer's facility. Parts should not be delivered without the prior agreement of the dealer or Auger Torque.

During the warranty period Auger Torque, at its option, will repair or replace any parts free of charge determined as defective by Auger Torque. Such repairs will be undertaken by Auger Torque or its nominated representative at an Auger Torque facility or a location deemed suitable by Auger Torque. Auger Torque are not liable for any associated costs relating to a warranty failure.

Parts repaired or replaced by Auger Torque are then covered by this warranty for the remainder of the original warranty as if such parts were original parts.

Products or parts which, as determined by Auger Torques examination, show wear from normal use, have been improperly operated, damaged by accident or negligence, altered or modified are not considered defective and are not covered by this warranty.

This warranty is void if any attempt is made to make field repairs unless these have been pre-approved in writing by Auger Torque.

This warranty is void if the products are not serviced in-line with the instructions in the Operators Manual. Particular care should be taken to perform regular oil changes in gearboxes.

This warranty is exclusive and in-lieu of any other expressed warranties. There are no warranties of merchantability or fitness for a particular purpose. Auger Torque shall not be liable for any consequential, incidental or punitive damages, losses or expenses, including those resulting from or caused by any defects.

As you would expect from Auger Torque, with our extensive experience and product reliability we'll always go the extra mile to keep you working.



YOUR DEALER IS

Auger Torque Europe Ltd
 Hazleton
 Cheltenham
 GL54 4DX
 England
 Tel:+44(0)1451 861652
 Fax:+44(0)1451 861660
 Email: sales@augertorque.com

Auger Torque Australia Pty Ltd
 122 Boundary Rd
 Rocklea
 Queensland 4106
 Australia
 Tel:+61(0)7 3274 2077
 Fax:+61(0)7 3274 5077
 Email: sales@augertorque.com.au

Auger Torque USA LLC
 100 Commerce Drive
 Huntington
 Indiana, 46750
 USA
 Phone: (+1) 260 200 1500
 Fax: (+1) 260 200 1501
 Email: sales@augertorqueusa.com

www.augertorque.com



Products and specifications subject to change without prior notice.
 Some products may not be available in your country or region.

AUGER TORQUE, SHOCK LOCK™, NDS™ and the AUGER TORQUE LOGO are trademarks of Auger Torque Europe Ltd © 2013 Auger Torque Europe Ltd. All Rights Reserved.